

SEC003

Installation Instruction



1. Take out the side baffle and the baffle and fix it with screws (note that the grooved side of the baffle should face inwards)



2. Take out the remaining bars and fix them with screws (note that the grooved side of the bars should face inwards)



3. Put up a shelf



4. Take out the layer board and insert it along the groove



5. Take out the other side panel and install it with screws



6. Erect the rack and the installation is complete