

# WAP006 Installation Instruction



It is highly recommended to use '**LePage No More Nails**' as the backing adhesive, which is available for purchase at Home Depot and Amazon.

