

CC052-2D

Installation Instruction



Please read this instruction manual carefully before installation and use.


Assembly notes:

1. First, make sure that all panels and parts are not damaged or missing.
2. During the installation process, be careful not to bump or scratch the panel surface.
3. Please read the instructions carefully before installation and install in order.
4. Please use each screw accessory strictly according to the instructions.
5. The slide needs to be split into two parts when in use. For the splitting method, see the slide instructions.
6. Please keep the packaging box in case of any problems. You can check the product model and production batch number printed on the outside of the packaging box.

Precautions after assembly:


1. After installation, check whether all parts are installed and the locks are locked.
2. Check the overall stability of the cabinet to see if there is any vibration.
3. When using the lock, do not use excessive force to avoid damage to the lock. Just turn it clockwise until it cannot turn.

NOTE: ES001 - 3 Speed Portable Cordless Electric Screwdriver is highly recommended for installation.



Scan the code to purchase ES001








CAUTION



TWO PERSONS LIFT & INSTALLATION


Important: This product is oversized and heavy. For safe assembly and to avoid damage, at least two people are required. When flipping or moving the item, always lift carefully. Never drag, drop, or handle it roughly.

Hardware List

Accessory Appearance	Code	Accessory Appearance	Code
	A		E
	B		F
 Black	C		G
 Black	D	 Gold	H


Detailed description of the main components, please read carefully
Hinge Installation Instructions

1.




Fold the hinges as shown in the diagram.

2.




Install the hinge onto the door and ensure it is secure.

3.




The height can be adjusted up and down here.

4.




Adjusting the gap between the door.

Installation Guide: Threaded Rod, Latch, Pre-drilled Hole




1. Screw the B (Threaded Rod) into the Pre-drilled Hole
2. Insert the installed A into the corresponding hole of the other piece. Press A (Latch) into the hole. Note that the cross arrow corresponds to the insertion direction of the Threaded Rod.
3. Use a cross screwdriver to tighten Latch clockwise. Be careful not to use excessive force.


Step 1



A




B




Install B into all white pre-installed holes. Connect panel 8 and 7, using A to lock.


Step 2



A




B




Install B into all white pre-installed holes. Attach panels 4 and 5 to the assembled unit, using A to lock.


Step 3



A




B




Attach panel 6 to the assembled unit, using A to lock.


Step 4



A




B




Install B into all white pre-installed holes. Attach panel 2 to the assembled unit, using A to lock.


Step 5



A




B




Install B into all white pre-installed holes. Attach panel 3 to the assembled unit, using A to lock.


Step 6



A




B




Install B into all white pre-installed holes. Attach panel 1 to the assembled unit, using A to lock.

Step 7

Step 7-1: Front facing up




Step 7-2: Back facing up





Flip the cabinet with the back facing up.

Step 8




Ruler not
included




Use a ruler to measure the diagonal on the back. If both measurements are the same, the cabinet is square and you can continue assembly. If they differ:

1. Check if any panels are installed incorrectly or reversed.
2. Ensure all panels are tightly connected and properly aligned.
3. Make sure all A fittings are fully tightened.
4. Gently adjust the cabinet by pushing it into alignment.

Step 9




F




Place back panels as shown, use F to secure them to the frame. A small hammer is required (not included).


Step 10



D




E




Install E onto the door. Secure E with D.

Step 11




C




Align the door with the edge and fix it to panel 2 using black screws C.

Step 12




C





Repeat the steps to install the other door onto panel 3.


Step 13



G



After securing part G, place the hanging rod onto it.



Position part G (the hanging rod) along the **centerline** of panel 2, approximately **6 cm** below panel 5. Repeat the steps on panel 3. Before securing with screws H, use the hanging rod to check that part G is positioned correctly.

Step 14



Installation Finished