


# SOCE009-50x17

## Installation Instruction




**Please read this instruction manual carefully before installation and use.**

### Assembly notes:

1. First, make sure that all panels and parts are not damaged or missing.
2. During the installation process, be careful not to bump or scratch the panel surface.
3. Please read the instructions carefully before installation and install in order.
4. Please use each screw accessory strictly according to the instructions.
5. The slide needs to be split into two parts when in use. For the splitting method, see the slide instructions.
6. Please keep the packaging box in case of any problems. You can check the product model and production batch number printed on the outside of the packaging box.






### Precautions after assembly:

1. After installation, check whether all parts are installed and the locks are locked.
2. Check the overall stability of the cabinet to see if there is any vibration.
3. When using the lock, do not use excessive force to avoid damage to the lock. Just turn it clockwise until it cannot turn.




**Note: Please be sure to use a manual screwdriver and refrain from using an electric drill.**

# Hardware List

Accessory Appearance	Code	Accessory Appearance	Code
	A		G
	B		H
	C		I
	D		J
	E		K
	F		

## Installation Guide: Threaded Rod, Latch, Pre-drilled Hole



1. Screw the B (Threaded Rod) into the Pre-drilled Hole
2. Insert the installed A into the corresponding hole of the other piece. Press A (Latch) into the hole. Note that the cross arrow corresponds to the insertion direction of the Threaded Rod.
3. Use a cross screwdriver to tighten Latch clockwise. Be careful not to use excessive force.

# J (Sliding Rail) Installation Instructions


When installing J, use with screw C

1, Separate J (Sliding Rail)



The main body part

The pull-out part






4. Install the main body part  
onto panel 1 and panel 2.

3, Pull the other end  
outward to separate.

2, Elastic clip strip,  
Press the board down to the  
bottom with your finger.

5, Install the pull-out  
part on panel 12



# Step 1



**B**


**F**

# Step 2





B

F




# Step 3




**B**

**F**




# Step 4



C


J

The main body part




When installing the main body of J, keep C facing straight down and tighten **halfway first**. Make sure all J parts are parallel, then fully tighten.


# Step 5



# Step 6




Please prepare a small hammer. It is **not included** with the product.




Insert the left and right brackets into the hole in panel 3.

# Step 7




Use E to connect panel 4 to panel 3, then use C to fix it on the bracket.

# Step 8





C

5





Install the wide layer panel on the bracket, use C to fix on the both side.

# Step 9





D

I




Install I to the door panel as shown.

# Step 10




**Insert G into the side hole of the door panel as shown.**  
**Note:** The pre-drilled hole may be obstructed. First, use G to position it, then use a hammer to gently tap G into the door panel.

# Step 11




Please pay attention to the positions of Panels No.6, No.7, and No.8, and make sure the groove direction of each panel is correct.


# Step 12




B




# Step 13



Disassemble part H as shown in the diagram, then attach it to the panel 14.




# Step 14




Note: Make sure each edge fits precisely into the groove.


# Step 15




# Step 16



A



# Step 17




**X 2**


# Step 18




A




# Step 19




A



# Step 20



# Step 21




# Step 22




A

2




Ensure Panel No.2 fits flush with the cabinet, with no gaps.

# Step 23




A




Ensure Panel No.2 fits flush with the cabinet, with no gaps.

# Step 24




C A





Secure 14 and 15 with C.

# Step 25




**B**



**12** X 2


**11** X 1



**17** X 1


**16** X 1

# Step 26




Note: Make sure all grooved edges are aligned in the same position. Pay attention to the panel orientation.

# Step 27




**Note:** Make sure all grooved edges are aligned in the same position. Pay attention to the panel orientation.

# Step 28




Note: The J pull-out part should be positioned with the closed side close to Panel No.11.




Then secure it with C.

# Step 29




D

1



# Step 30



Insert into the slots on both sides at the same time.

# Installation Finished

